

SYNCRO AS NETWORKING



The flexibility of the Syncro System can be further enhanced by connecting control panels and repeaters together using a high integrity network.

A simple 2-wire connection between each panel allows events to be transmitted to other parts of the system to provide indication or control on a system wide basis.

Using the Loop Explorer configuration programme, up to 64 nodes can be programmed to respond in a variety of ways to any system events as required.

This flexibility extends the comprehensive cause and effect programming capability of Syncro control panels to the entire network allowing actions, test modes or disablements to be started from any point.

The fault tolerance of the network is such that that any single open or short circuit fault will not result in any loss of information. Multiple faults are isolated and the network breaks into smaller networks which continue to work autonomously.

FEATURES

- Up to 64 nodes.
- High integrity protocol.
- Fully secure against short or open circuit faults.
- Simple 2-wire loop connection.
- Repeaters share network connection.
- Network wide test and disablement functions.
- Network wide cause and effect logic.
- Flexible configuration options.
- Panels configurable to act on a network events or not as required.
- Apollo & Hochiki panels supported on single network.

REF: DAKK555_122024_REV0

AQL PROTECCION

Carretera N-340 Km 1245, 3 Nave B-5 Polígono industrial El Pla 08750 Molins de Rei, Barcelona (España) Tel. (+34) 936800376 * WhatsApp pedidos: 660781482 * <u>www.aqlproteccion.com</u> * <u>aql@aqlproteccion.com</u> ANBER


Avda. de las Flores, 13-15 P.E. El Molino 28970 Humanes de Madrid, Madrid (España) Tel. (+34) 916063711 * WhatsApp pedidos: 649787619 * <u>www.anber.es</u> * <u>anber@anber.es</u>

SPECIFICATION

Configure Panel Settings				Syncro						
Panel Data Times Neh	weak In	leiface	1							
The panel will Click the + b NOTE - if the proce Advisvedge an	utton i	ext to a	each ne each ne ead for	twork pane the Status e	nt types for I icon to vie svent, then ected netw	w the even the park lock panel	enit respon	ese optio	ins te Rese	6
Network		_	_			vent		_		
Panel		Evac		PreAlam	Security	Fault	Disab	Tech	-	Status
🛛 🔂 02 - Hochiki Panel	1			× .				-	*	
O Process	~	4			~	~	~		1	
Oisplay			•	~	~					
QLog.			~	~		*				~
Print		4	~			~	~	4	•	
Buzz		•		~						Y
C 3 · Apollo AS	1		~			~	~			
Process			•		*	*	*		*	
O Display	1			~		~				
♦Log	4	4				~	~	-		
Print	-		-			~	~		~	~
Butz						~			~	~
104 - Hochiki AS	4	4	*	*	-	~	1	*	1	4

Flexible network configuration options using simple to follow PC configuration programme.

Two core loop wiring ensures network integrity by providing full isolation of faulty wiring segments.



Two core loop wiring ensures network integrity by providing full isolation of faulty wiring segments.

Product code	K555				
Protocol	RS485				
Connection	Two wire loop				
Current consumption	40mA				
Integrity	Full isolation of faulty nodes or wiring segments				
Indicators	Data in and data out communications status				
Cable length	Tres to adjacent nodes				
Cable type	Belden 9271, Belden 9860, FP200 Gold				
Compatible panels	Syncro AS (required for networking)				

REF: DAKK555_122024_REV0

AQL PROTECCION

Carretera N-340 Km 1245, 3 Nave B-5 Polígono industrial El Pla 08750 Molins de Rei, Barcelona (España) Tel. (+34) 936800376 * WhatsApp pedidos: 660781482 * <u>www.aqlproteccion.com</u> * <u>aql@aqlproteccion.com</u> ANBER

Avda. de las Flores, 13-15 P.E. El Molino 28970 Humanes de Madrid, Madrid (España) Tel. (+34) 916063711 * WhatsApp pedidos: 649787619 * <u>www.anber.es</u> * <u>anber@anber.es</u>